Contents

V1.5

INTRODUCTION 1

PLAYER CONTROLS 1

NAVIGATION BAR 2

MY TV 3

SOURCE INPUT 3

CHANNEL LIST 3

SCHEDULE 4

TV SETTINGS 5

EPG 7

TV CONTROL BAR 7

MY VIDEOS 8

RECORDING VIDEOS: 8

MORE VIDEOS 8

SETTINGS 9

VIDEO CONTROL BAR 9

PICTURES 10

SNAPSHOT PICTURES 10

MORE PICTURES 10

SETTINGS 11

PICTURE CONTROL BAR 12

RADIO 13

CHANNEL LIST 13

SCHEDULE 13

SETTINGS 14

RADIO CONTROL BAR 16

SETTINGS 17

TV 17

VIDEOS 17

PICTURES 17

RADIO 17

GENERAL SETTINGS 18

Introduction

Thank you for choosing this Genius product. Before you start using your system, read this manual carefully and follow the installation instructions.

HyperMedia Center is an integrated multimedia application that allows you to enjoy all of your digital entertainment - TV, home videos and photos. HyperMedia Center is especially designed for turning your PC/Laptop into an entertainment solution.



Player Controls

There are several methods to control HyperMedia Center

• By Keyboard

Control the application by using the **Arrow keys**, **ESC**, and **Enter** keys.

• By Mouse

Select items by left-click or scroll wheel.

• By Remote Control (optional: depends on the model)

Navigation Bar



	Return to Home page
	Return to previous page
	Minimize HyperMedia Center to the task bar.
	Adjust the display size
	Exit HyperMedia Center.

My TV

HyperMedia Center is an all-in-one entertainment solution for the modern life. Now you can watch and record your favorite TV programs anytime you like. The first time you run HyperMedia Center, the setup wizard will guide you to configure the TV settings.



Source Input


Choose your TV signal source such as TV / Composite / S-Video.

Channel List

It will assist you to select TV channel.

Schedule

Schedule the recording of TV program. If you want to cancel a schedule, enter the **Schedule** and choose **Cancel**.



Source Input: Select your TV signal source.

Channels: Choose the channel you want to record

Scheduling Interval: Define the recording rules. The default value is "Once only".

Starting Date: Set the recording date.

Starting/Ending Time: Set the Time to start/end recording (hour/minute).

TV Settings

Adjust TV signal, recording and display settings here.




Run Setup Wizard: Run Setup Wizard is an easy setup function. It can help you to complete the overall settings of TV function including TV tuner, region and automatic scan of TV channels.


Recording Settings: Configure the recording format: MPEG 1/2/4 (Analog only)

For digital TV system, you cannot change the setting because it only supports the default MEPG II format.


Display Settings: Adjust the display settings (**Brightness**, **Contrast**, **Saturation**, **Hue**, **Sharpness** or **default setting**)



Extra Display Settings: Adjust the display aspect ratio (**4:3, 16:9, 16:10**)



Extra Display Settings: De-noise function for Analog TV. Open it will improve Analog TV quality.



EPG

EPG (Electric Program Guide) allows you to receive the information for each channel.

TV Control Bar



	Stop		Pause		Backward
	Forward		Time-Shifting		Capture
	Snapshot		Close Caption		Subtitle
	Channel Preview		SAP		Previous Channel
	Next Channel		Volume Down		Mute
	Volume Up		Switch to Hypermedia center		

My Videos

In the Videos page, you can play video files stored in your computer.



Recording Videos:


Play the video files in a specific folder.

More Videos

HyperMedia Center is also applicable for playing other video files.

Settings

Create a specific folder to save recorded video files.



Video Control bar

		Backward
		Pause
		Forward
		Stop

Pictures

In **My Pictures** page, you can view pictures stored in any folder.



Snapshot Pictures


Click **Snapshot Pictures** button to review the picture files you captured. In addition, you can also check pictures in the slideshow mode.

More Pictures


Show other picture files in your computer.

Settings


In Settings, you can create a specific folder to save pictures. Meanwhile, the timeframe of Slideshow can also be set in this option. Besides you can set multi-snapshot pictures from 1 to 10 in “Total pictures” option, and set “Time interval” from 0.2sec to 10sec.




SlideShow Interval: Configure the interval : 1sec , 3 sec , 10sec or 30sec




Format of snapshot picture: Please select your favorite format: BMP or JPEG



Total Pictures: Configure Multi-Snapshot pictures: From 1 picture to 10 pictures



Time interval: Configure Multi-Snapshot interval: From 0.2sec to 10 sec



Picture Control bar

		Stop
		Backward
		Forward
		Slideshow

Radio

This model doesn’t support FM radio.

Channel List

It provides a channel list for you to select the preferred FM program.

Schedule


Schedule allows you to schedule the recording of FM program. You can set up a new schedule to record the FM program, or choose **Cancel** if you wish to call off the recording request.

Settings

In **Radio**, it allows you to choose saving destination of the FM recording files. More than that, you can also set up the recording format and channel scanning in this option.



Recording Format: Configure the recording format: WAVE or WAM



Scan Interval: Configure scan channel interval: 0.1 MHz or 0.05 MHz.



FM RDS function: Click the right mouse button and it will pop-up a small window.

Select “RDS on” and click left mouse button to enable RDS function.




Radio Control Bar



	Stop		Pause		Backward
	Forward		Capture		Tune Downward
	Last receivable FM Station		Memorize FM Station		Next receivable FM Station
	Tune upward		Last Preset FM Station		Next Preset FM Station
	Mute		Volume Up		Volume Down

Settings

Click Home Page to open the HyperMedia Center Setting menu. Here you can find the general settings for HyperMedia Center software, and duplicated control settings for other options such as **TV**, **Videos** and **Pictures**.



TV

Please refer to the setting description in **TV** section

Videos

Please refer to the setting description in **Video** section

Pictures

Please refer to the setting description in **Picture** section

Radio

Please refer to the setting description in **Radio** section

General Settings

In General Settings, there are many options for you to choose:

Language: English, Chinese, French, German, Russian and Spanish, Multi-language to meet your need.

Background Color: 10 vivid backgrounds for you to select. It is wonderful to freshen up your vision by changing background colors every day.